

TD5428 HEAVY HITTER BOLLARD INSTALLATION INSTRUCTIONS

Using a 2-inch Masonry drill bit, drill a 2" diameter hole to a depth of 4.25 inches.



Measure the depth of the hole. Recommended depth is 4.25 inches.



Blow out the hole. Clean road or walkway surface of dirt and dust. Please remember to wear safety glasses!



Fill hole with two-part epoxy to within 2 inches of the top of the hole.



Place Heavy Hitter anchor with glue guard and supplied bolt in hole and firmly press and twist anchor against road surface. Make sure anchor stays against road surface.



After epoxy is cured, install Heavy Hitter until firmly against road surface, then installation is complete. (Relton Cutter Head #SB-32 2" - Relton Shank #SMX-10 - Hilti HY 200-AV3)

