



## **INSTALLATION PROCEDURES**

### **27" GUARDFLEX GUARD RAIL DELINEATOR**

### **TD9100 SERIES**

The TD9100 Guardflex series can be mounted on wooden or steel guardrail support posts by using self sealing nails or self tapping screws placed in the pre-molded holes provided on the delineator. Install with the sheeted side facing traffic. Worker safety and the proper handling of tools and equipment are important and should be followed at all times. Personal protection gear such as eye, hearing protection and gloves should be worn at all times.

#### **Installation Procedure for Steel Posts Using Screws**

1. Place delineator with self tapping screws in position at the desired post or rail.
2. Plumb the delineator so it is vertical and the top of the flexible delineator is 48" from the surface of the roadway.
3. Drill a self tapping, #8 screw into the post or rail until the delineator is flat against the post by the screw's nylon sealing washer.
4. Repeat for the drilling of the second screw to complete the installation.

#### **Installation Procedure for Wood Posts Using Nails**

Place delineator with self sealing, 11 gauge (6d) x 2", in position at the post.

Plumb the delineator so it is vertical and the top of the flexible delineator is 48" from the surface of the roadway.

Drive the nails with the hammer into the post until the delineator is flat against the post by the nail's sealing washer.